


# Users manual/Használati útmutató

## SALLY overdrive



1. DC 12V power connector (centre negative, 5.5/2.5 mm). We recommend the use of the Hunor power supplies!
2. Tube sockets with tubes.
3. Output 6.3mm jack connector.
4. Input 6.3mm jack connector.
5. Volume pot, adjust the output level of the effect.
6. Tone pot, adjust the high frequencies of the output signal.
7. Gain pot, adjust the gain of the tube overdrive.
8. Effect ON/OFF state indicator LED.
9. Footswitch for switching effect ON/OFF.

1. DC 12V (center negatív, 5.5/2.5mm) tápcsatlakozó.
2. Elektroncsövek.
3. Kimenet, 6.3mm jack csatlakozó.
4. Bemenet, 6.3mm jack csatlakozó.
5. Volume potenciométer a kimeneti jelszint beállításához.
6. Tone potenciométer a kimeneti jel magas frekvenciáinak beállításához.
7. Gain potenciométer a torzítás szintjének beállításához.
8. Effekt BE/KI állapotjelző LED
9. Lábkapcsoló az effekt BE/KI kapcsolásához.